# **Perf Cluster Strategies**

Liberty Engineering Solution



## **Rock** Permeability Drives Optimized Frac Spacing


Impacts Stage Spacing and Perforation Clustering Decisions

#### **Higher Permeability Rock**

- Requires fewer fracs
- Too many clusters/stages cause "wasteful" production interference
- Need fracture conductivity

#### **Lower Permeability Rock**

- Requires more fracs
- More effectively contributing clusters essential for economics
- Need fracture complexity





# **Shale Revolution Frac Trends**

Creating Larger and Denser Fracture Networks


2014 2017 • Larger fracture network 1200 acing (ft) • Horizontal wells Stabilizing ft/stage 800 • Longer laterals • Increase in proppant mass Increasing clusters/stage 15 Increase in fluid volume • Denser fracture distribution 80 • Higher stage count Slightly Increasing perforations/stage • Higher pump rate • Changes in perf 20 clustering 1.20 Cost-sensitive 1.00 Increasing rate/ft/stage • Fewer additives 0.80 0.60 e/Lat I Local proppant 0.40 0.20 Max 0.00



### **Creating More Effective Perf Clusters**

eXtreme Limited Entry (XLE) Design


XLE Impact on Initial Perf Cluster Efficiency Middle Bakken





## **Creating More Effective Perf Clusters**

eXtreme Limited Entry (XLE) Design



Step Down Analysis:

The Step Rate Test performed pre- & post-proppant

• SPE 62549 L. Weijers, C.A.Wright...et al)

# Multi-well calibration has resulted in a 75% holes open design assumption:

- XLE strategy increased % perfs open by 5 10%
- Max rate before S/D Test impacts the number of holes initially open
- Intra-stage σ<sub>Hmin</sub> variability impacts % of holes open





# **Perf** Cluster Strategies

The Liberty Difference Produces Better Wells

- Optimized perforation cluster design depends on reservoir characteristics O Liberty's DFIT evaluation provides vital input data
- Stepdown Tests provide real-time assessment of cluster efficiency
- An effective perforation cluster design

   Can improve well performance
   May help you save on frac stage count
- Before your frac job turns into a cluster frac, consider Liberty

   Help with your perf cluster strategy
   Pump your job effectively





### LIBERTYFRAC.COM